

SR-8000 HYBRID Accessory Kit Quick Guide

Thank you very much for purchasing our product.
This quick guide describes the precautions for your work before using.
The select Accessory Kit option is only for SR-8000HYBRID. You need the main body of SR-8000HYBRID (here after, call "the main body") to use the select Accessory Kit option. Please surely read the instruction manual before using.
Please also read the operation manual in the CD-ROM which is belonging to the product, and use the product properly and safely.
Please keep the manuals and the CD-ROM in safe.
For detail, please refer to ¥English ¥Manual ¥Operating manual.pdf in the CD-ROM.

Notice





Please make sure to read “Safety Precautions”









Safety Precautions

Handling the Device Correctly and Safely












Read the "Safety Precautions" carefully before using, and use this product correctly.
This "Safety Precautions" page lists graphic to ensure the safe operation of this product to prevent users, other people or property from being damaged. Thoroughly read these precautions and understand the meaning of the symbols before proceeding to the main text of this manual.











■ The levels of danger and damage that will arise if the device is inappropriately used are classified and indicated as shown below.






 WARNING	Improper operation by neglecting this instruction may result in personal death or serious injury.
 CAUTION	Improper operation by neglecting this instruction may result in personal injury or property damage.
 NOTICE	Precautions and restrictions for operating the device. Be sure to read carefully to prevent improper operation.
 NOTE	Indicates additional information about the controls or related functions. Reading these is recommended.




How to Handle Power Cord and Power Plug	
	<ul style="list-style-type: none">● Stop using the device immediately in the event of abnormal operation or a breakdown, and unplug the power cord.● The device emits smoke or a strange odor or noise.● Liquid such as water or a foreign matter enters inside.● The power plug gets abnormally hot.● There is deformation or damage to the device. If the product is used as is, a fire or an electric shock may result. * Immediately turn the power switch off and contact the sales shop. Never attempt to repair by yourself since it may cause serious danger.
	<ul style="list-style-type: none">● Make sure the power outlet is within reach so the power cord can be easily unplugged.● Make sure the plug is firmly inserted into the outlet.
	<ul style="list-style-type: none">● Do not use the device with other supply voltage than the specified one.● Use only appropriately rated outlet and wiring tools.● Avoid the use of multi-socketed adapters. This may cause a fire due to heat generation.
	<ul style="list-style-type: none">● Do not damage the power cord or power plug. This may cause a fire due to an electric shock or short circuit.
	<ul style="list-style-type: none">● Use only the specified power cord and power plug. Otherwise it may cause a fire or an electric shock.
	<ul style="list-style-type: none">● Do not use the power cord while rolled up. This may cause a fire due to heat generation.
	<ul style="list-style-type: none">● Do not pull the cable when unplugging the power cord. Damage to the power cord or deformation of the plug can cause a fire or an electric shock.
	<ul style="list-style-type: none">● Do not touch the power plug or the device itself during a thunder and lightening storm. This may result in an electric shock.

■ The following graphic symbols explain the necessary actions to be taken.

	Indicates warning and precautions. The exact warnings and precautions are shown in the symbols.
	Indicates prohibited actions. The exact prohibited actions are shown in the symbols.
	Indicates actions that must be carried out. The exact required actions are shown in the symbols.
 WARNING	
	Only the person who was trained for maintenance/service work can permit preparation of the main body. When those who was not trained for maintenance/service work, there is a danger of getting injured.
	<ul style="list-style-type: none">● Do not place your hand on the paper feeding surface while the device is in operation. Your hand can be caught and injured due to incorrect usage.
	<ul style="list-style-type: none">● Do not place your hand into any moving parts while the device is in operation. Your hand can be caught and injured due to incorrect usage.
	<ul style="list-style-type: none">● When placing your hand on the paper feeding surface during a paper jam, be careful not to allow your fingers to be caught or hit. Your finger or hand can be caught on the paper feeding surface or the upper cover and this may result in a injury. Turn the power switch off while working.
	<ul style="list-style-type: none">● Do not touch the motor part inside the stacker while the device is in operation or immediately after turning off the power. Caution: High temperature High heat may cause burns.
	<ul style="list-style-type: none">● Equipment used in an environment without children. This may result in an accident or injury.
	<ul style="list-style-type: none">● Do not place the storage bags in the package within reach of children or near fire. If placed in the mouth or over the head, this may result in an accident or cause suffocation. Do not place near fire, or it may cause a fire.

How to Handle the Device	
	<ul style="list-style-type: none">● Do not connect or disconnect the power plug with a wet hand. This may cause electric shock.
	<ul style="list-style-type: none">● Connect a ground cable and ground the device. Be sure to ground the device with a ground cable. Otherwise, an electric shock may occur.
	<ul style="list-style-type: none">● When connecting or disconnecting the ground cable, unplug the power cord first. Otherwise, an electric shock may occur.
	<ul style="list-style-type: none">● Do not spray organic solvent such as flammable fluids or paint thinner. Flammable gas remaining inside the device can catch fire from static electricity, which may cause a fire, burn or injury.
	<ul style="list-style-type: none">● For internal inspection, adjustment or repair of the product, contact the distributor. Caution: High Pressure Only service staff should remove the cover. Do not attempt to do this yourself as it may cause an electric shock.
	<ul style="list-style-type: none">● Do not modify the device, remove the cover or disassemble it. There is a high voltage part inside. It may cause a fire or an electric shock.
	<ul style="list-style-type: none">● Do not place the device in areas subject to liquid, dust, or humidity. This may cause a fire.
	<ul style="list-style-type: none">● Don't insert or drop foreign objects such as metals or flammables into the opening. This may result in a fire or an electric shock.
	<ul style="list-style-type: none">● Do not place a container with liquid or a metal piece on the device. This may cause a fire.
	<ul style="list-style-type: none">● Do not use in a place where there is explosive, combustible or flammable gas. It is extremely dangerous to use the device in a place where there is explosive, combustible or flammable gas. You must not do this .








⚠CAUTION	
	<ul style="list-style-type: none"> ● Before moving the device, make sure to unplug the power cord from the outlet. If the power cord is damaged, a fire or an electric shock may occur.
	<ul style="list-style-type: none"> ● Do not install on an unstable surface. Do not place or install the device on an unstable surface. It may fall, resulting in an injury.
	<ul style="list-style-type: none"> ● Avoid using the device in the following places as this may cause malfunction. <ol style="list-style-type: none"> 1. a place receiving radiant heat (such as direct sunlight) 2. a place above altitudes above 2,000 m (6,561feet) 3. a place where mechanical vibration frequently occurs 4. a place near the source of an electromagnetic field 5. a place where dust and oily smoke are frequently released 6. a place prone to steam, water or condensation 7. an environment that contains organic gas, inorganic gas or salinity.
	<ul style="list-style-type: none"> ● The device should only be used indoors. Do not use it outdoors. This may cause a fire or malfunction.
	<ul style="list-style-type: none"> ● When the device is not in use for a long time, remove the power cord for safety.

Maintenance Notes	
	<ul style="list-style-type: none"> ● Regularly wipe off dust on the power plug. If dust builds up on the power plug, it may cause problems in insulation, which could lead to a fire. *Unplug the power cord and wipe with a dry cloth.
	<ul style="list-style-type: none"> ● Unplug the power cord before cleaning for safety. Failure to so may cause an electric shock, fire or injury.
	<ul style="list-style-type: none"> ● Do not use volatile chemicals like paint thinner or benzene or a wet cloth When cleaning, wipe gently with a dry soft cloth. Do not use volatile chemicals like paint thinner or benzene or a wet cloth. Avoid getting the sensor part wet. This may cause malfunction.

NOTICE
<p>Do not dispose of the device with general household waste. Waste electrical product disposal must be conducted according to the regulations of the area or the relevant local government.</p>

This completes Installation of the unit.
For further installation, please refer the instruction manual belonging to the product and the operating manual in the CD-ROM.

Before Using
Before setting up the unit, check to confirm that all of the below items are included in the package.
If you find any missing or damaged items, please contact your dealer.

Paper receiver	Paper discharge brackets	Paper discharge guide sheet
		
Rubber leg × 4 pcs	Bind screws (M4 × 8: 4 pcs)	TP Screw, black (M3 × 6 : 1 pcs.)
		
Accessory kit quick guide (this book)		
		

SEKONIC CORPORATION

7-24-14, Oizumi-Gakuen-Cho, Nerima-Ku, Tokyo
178-8686 Japan
Tel +81-3-3978-2375 Fax +81-3-3922-2144
<https://www.sekonic.com>