



Before use the SR-450

Procedure for install the USB Driver

In order to use USB interface in the SR-450, you first need to install*1 USB Driver.
If the old SR-450 USB driver is installed, please uninstall it first.

Before you connect SR-450 and computer, you first need to install the USB Driver from the bundled CD-ROM. The following are the procedures for installation. (Refer to the details from page 6 “4. Install the USB driver” in the Instruction manual).

Without installing USB driver into your computer, you will not have any operation*2.

*1 This installing is needed to log-in from administrator domain for the computer. Internet connection required for digital signature authentication.

*2 When you try to install again just in case you think you missed, please do the un-installing it.

Please refer to Page 11 “4-E un-installing procedure” which describes procedure of un-installing.

(System Requirements)

OS : Windows 10 version 21H2 and later (32bit,64bit) , Windows 11 (64bit)
(Windows on Arm is not supported.)

Computer : Computer equipped with USB interface as standard

※ Please check our website for the latest information. (<http://www.sekonic.co.jp/omr>)

(Process of USB driver install)

① (For 32bit OS)Click "English\Driver\sr450usbInstaller_x86.exe"
in the accessory CD-ROM.

(For 64bit OS)Click "English\Driver\sr450usbInstaller_x64.exe"
in the accessory CD-ROM.

The Installer is displayed some messages, then,
please refer and proceed installation.

② Turned on SR-450 and connect with computer, The USB
driver can be automatically recognized for Windows.

