# SEKONIC
# Light Meter
# Quick Guide
# DIGITALMASTER
# L-758 Series

## Parts Designation




* Measuring button and memory button are used in common.

* Press twice using JOG WHEEL to turn on.

## Basic Operation

### On/Off

Press down POWER BUTTON to turn on meter. Battery icon will appear ▮▮▮ with 3 status of icon. Press and hold POWER button to turn off.

### Set ISO 1 or ISO 2

Press and hold MODE button and turn JOG WHEEL. Select ISO 1 or ISO 2 while turning the JOG WHEEL.

### 1°Spot Reflected Mode

Turn INCIDENT/SPOT SELECTOR DIAL to ◪ to select 1°Spot.

Press MEASURING BUTTON.

Turn INCIDENT/SPOT SELECTOR DIAL to ● to select Spot.

### Incident Mode

Press MEASURING BUTTON.

### Ambient Light

Luminance in donom position wors as lumindec wnrh is useful for measuring of illuminance or lighting ratio.

### Lumindec

Select EV Readout mode by holding down the MODE BUTTON and turning JOG WHEEL. Press the MEASURING BUTTON. EV mark will appear. Press MEASURING BUTTON. Select EV Readout mode by holding down the MODE BUTTON and turning JOG WHEEL. Press the MEASURING BUTTON again simultaneously to return to the main menu.

### EV Readout - Option

Item 1 (EV) in the OS settings is turn on EV mode. Select Ambient mode. Hold down the MODE BUTTON and turn JOG WHEEL until EV mark appear. Press MEASURING BUTTON. Select Cord Flash mode by holding down the MODE BUTTON and turning JOG WHEEL. Press the MEASURING BUTTON.

### Cord Flash Mode

Select Cordless Flash mode. Select ⑦ Cordless Flash Mode. Press MEASURING BUTTON and mark ⑦ will blink for 90 seconds. During this time, trigger the flash manually and light meter measure and display the reading.

### Cordless Flash Mode

Select ⑧ Wireless Flash Radio Triggering Setting Mode. Hold down MODE BUTTON and turn JOG WHEEL to select sub-channels ⑧ 1, ⑧ 2, ⑧ 3, ⑧ 4. Simply press the direct function button: ISO 1 ■, ISO 2 ■, MID.TONE ■, M.CLEAR ■ on the side of corner on LCD. Each alternate value is confirmed. Press MEASURING BUTTON once returns to the screen to the main menu.

### Wireless Flash Radio Triggering Setting Mode

(With optional radio transmitter module for L-758D or the L-758CINE) Select ⑧ Wireless Flash Radio Triggering Setting Mode. Hold down MODE BUTTON and turn JOG WHEEL to select sub-channels ⑧ 1, ⑧ 2, ⑧ 3, ⑧ 4. Simply press the direct function button: ISO 1 ■, ISO 2 ■, MID.TONE ■, M.CLEAR ■ on the side of corner on LCD. Each alternate value is confirmed. Press MEASURING BUTTON once returns to the screen to the main menu. Trigger flash repeatedly and target flash is activated.

### Multi Flash Mode - Option

Up to 9 Custom Settings (Data) can be stored. Press MEASURING BUTTON to enter the measurement data to be stored and displayed. Press MEMORY BUTTON. Up to nine memorize data will be stored and displayed in the analog scale by repeating this procedure. A Nth measurement can also be displayed simultaneously.

### Memory Function

When pressing MEMORY CLEAR button once, the last values, before the last one, will be deleted. Press MEMORY CLEAR button and press MEMORY CLEAR button.

### Memory Clear

To enter Memory Recall mode, hold down MODE button and press MEMORY button. and the "M" and number will blink.Rotate JOG WHEEL to recall memorized data. To exit Memory recall mode, hold down MODE button and press MEMORY button again. and "M" and number will stop blinking.

### Memory Recall

Take a measurement when button is pressed. Press MEASURING BUTTON. Up to nine values can be stored and displayed in the analog scale by repeating this procedure. A Nth measurement can also be displayed simultaneously.

### MID.Tone Setting

Select ⑧ Ambient mode by holding down the MODE button and turning JOG WHEEL. Press the MEASURING BUTTON. Select ⑧ Ambient Mode by holding down the MODE BUTTON and turning JOG WHEEL. Press the MEASURING BUTTON.

### Ambient Light

Select ⑧ Ambient Mode by holding down the MODE BUTTON and turning JOG WHEEL. Press the MEASURING BUTTON. Select ⑧ Ambient Mode by holding down the MODE BUTTON and turning JOG WHEEL. Press the MEASURING BUTTON.

### Daylight/Ambient Mode

Select ⑧ Ambient Mode by holding down the MODE BUTTON and turning JOG WHEEL. Press the MEASURING BUTTON. Select ⑧ Ambient Mode by holding down the MODE BUTTON and turning JOG WHEEL. Press the MEASURING BUTTON.

### Cordless Flash Mode

Select ⑦ Cordless Flash Mode. Press MEASURING BUTTON and mark ⑦ will blink for 90 seconds. During this time, trigger the flash manually and light meter measure and display the reading.

### Cordless Flash Mode

Select ⑧ Wireless Flash Radio Triggering Setting Mode. Hold down MODE BUTTON and turn JOG WHEEL to select sub-channels ⑧ 1, ⑧ 2, ⑧ 3, ⑧ 4. Simply press the direct function button: ISO 1 ■, ISO 2 ■, MID.TONE ■, M.CLEAR ■ on the side of corner on LCD. Each alternate value is confirmed. Press MEASURING BUTTON once returns to the screen to the main menu. Trigger flash repeatedly and target flash is activated.

### Wireless Flash Radio Triggering Mode

(With optional radio transmitter module for L-758D or the L-758CINE) Select ⑧ Wireless Flash Radio Triggering Setting Mode. Hold down MODE BUTTON and turn JOG WHEEL to select sub-channels ⑧ 1, ⑧ 2, ⑧ 3, ⑧ 4. Simply press the direct function button: ISO 1 ■, ISO 2 ■, MID.TONE ■, M.CLEAR ■ on the side of corner on LCD. Each alternate value is confirmed. Press MEASURING BUTTON once returns to the screen to the main menu.

### Multi Flash Mode - Option

Up to 99 Custom Settings (Data) can be stored. Press MEASURING BUTTON to enter the measurement data to be stored and displayed. Press MEMORY BUTTON. Up to nine memorize data will be stored and displayed in the analog scale by repeating this procedure. A Nth measurement can also be displayed simultaneously.

### Memory Function

When pressing MEMORY CLEAR button once, the last values, before the last one, will be deleted. Press and hold MEMORY CLEAR button and press MEMORY CLEAR button.

### Memory Clear

To enter Memory Recall mode, hold down MODE button and press MEMORY button. and the "M" and number will blink.Rotate JOG WHEEL to recall memorized data. To exit Memory recall mode, hold down MODE button and press MEMORY button again. and "M" and number will stop blinking.

### Memory Recall

Take a measurement when button is pressed. Press MEASURING BUTTON. Up to nine values can be stored and displayed in the analog scale by repeating this procedure. A Nth measurement can also be displayed simultaneously.

### MID.Tone Setting

Select ⑧ Ambient mode by holding down the MODE button and turning JOG WHEEL. Press the MEASURING BUTTON. Select ⑧ Ambient Mode by holding down the MODE BUTTON and turning JOG WHEEL. Press the MEASURING BUTTON.

### Ambient Light

Select ⑧ Ambient Mode by holding down the MODE BUTTON and turning JOG WHEEL. Press the MEASURING BUTTON. Select ⑧ Ambient Mode by holding down the MODE BUTTON and turning JOG WHEEL. Press the MEASURING BUTTON.

### Daylight/Ambient Mode

Select ⑧ Ambient Mode by holding down the MODE BUTTON and turning JOG WHEEL. Press the MEASURING BUTTON. Select ⑧ Ambient Mode by holding down the MODE BUTTON and turning JOG WHEEL. Press the MEASURING BUTTON.

### Cordless Flash Mode

Select ⑦ Cordless Flash Mode. Press MEASURING BUTTON and mark ⑦ will blink for 90 seconds. During this time, trigger the flash manually and light meter measure and display the reading.

### Cordless Flash Mode

Select ⑧ Wireless Flash Radio Triggering Setting Mode. Hold down MODE BUTTON and turn JOG WHEEL to select sub-channels ⑧ 1, ⑧ 2, ⑧ 3, ⑧ 4. Simply press the direct function button: ISO 1 ■, ISO 2 ■, MID.TONE ■, M.CLEAR ■ on the side of corner on LCD. Each alternate value is confirmed. Press MEASURING BUTTON once returns to the screen to the main menu. Trigger flash repeatedly and target flash is activated.

### Wireless Flash Radio Triggering Mode

(With optional radio transmitter module for L-758D or the L-758CINE) Select ⑧ Wireless Flash Radio Triggering Setting Mode. Hold down MODE BUTTON and turn JOG WHEEL to select sub-channels ⑧ 1, ⑧ 2, ⑧ 3, ⑧ 4. Simply press the direct function button: ISO 1 ■, ISO 2 ■, MID.TONE ■, M.CLEAR ■ on the side of corner on LCD. Each alternate value is confirmed. Press MEASURING BUTTON once returns to the screen to the main menu. Trigger flash repeatedly and target flash is activated